



# Installation for Raspberry



## Hardware requested

- Raspberry Pi 2 Model B (~ \$30)
- Alternative: Raspberry Pi Model B+ (~ \$30, predecessor of the RPI 2 Model B)
- Case for the RPI (~ \$10, if you want the HDD, buy HDD enclosure too for ~\$10)
- Aluminum heatsink set (~ \$5)
- Power supply (~ \$9)
- MicroSD card (~ \$8-\$17, I recommend getting one with at least 16GB of space, and class 10)
- Hard Drive WD PiDrive 314Gb, (~ \$40, if you want to use fast and heavy storage)
- Ethernet cable (~ \$8)
- Alternative: WiFi USB adapter (if you don't want to use a cable)
- Optional GSM gateway if you plan to not use Voip (~ \$200, for a Goip 4 channels)

Global price should be ~ \$200 in standard (without the GSM gateway).



You different environment to install the Voxibot suite for Raspberry :

### 1) Native Raspbian 8

[\[Install on Raspbian\]](#)

### 2) RasPBX : Integrated Asterisk/FreePBX

[\[Install on RasPBX\]](#)

### 3) Raspbian 8 with the WD HardDrive

[\[Install on WD HDD\]](#)

From:  
<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:  
[https://wiki.voximal.com/doku.php?id=installation\\_guide:raspberry:start&rev=1477438025](https://wiki.voximal.com/doku.php?id=installation_guide:raspberry:start&rev=1477438025)

Last update: **2016/10/25 23:27**

