

DIDx Incoming calls


- **Web site** : <https://www.didx.net/>

DID Exchange is a VOIP-based wholesale DID Phone Number marketplace which can and is used by Mobile Operators, LECs, CIECs, IXC's or other telecommunications service providers who offer or use any kind of PHONE NUMBERS in there network.

DIDx offers only inbound call services for DID's. You have a mounthly fee (some dollars), and a volume of minutes, if you overlap this you pay the call durations.

- **Configuration** :

By default the Voxibot installer create an account to receive external incoming calls. You need to get the password of the instance (voximal show licence). In the DIDx interface after purchased a DID number go to the configuration panel and set :



Change the RingTo :

A screenshot of a web form titled "Edit Ring To Address". The form contains the following fields and options:

- DID Number**: 33170613095
- Current IAX**: access:[redacted]@lab.ulex.fr/0001
- Enter your new RING TO Settings below:**
- New SIP**:
- New IAX**: access:xxxxxxxx@lab.ulex.fr/0001
- Default**: 1 Change Default RingTo
- To Test DID**: 18005558355@tf.voipmich.com
- Update**: A button at the bottom of the form.

New IAX : access:[your access password]@[your server IP]/[your DID to refere in the Voximal account]

Note : If you have strict firewall rules enable the 4569 traffic from the DIDx list : ¹⁾

¹⁾ link|<http://kb.didx.net/tiki-index.php?page=IP%20Addresses>

From:
<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:
<https://wiki.voximal.com/doku.php?id=voipproviders:didx&rev=1473265668>

Last update: **2016/09/07 16:27**

