

IAX Softphone Configuration

- **Web site** : <http://www.voip-info.org/wiki/view/IAX>

Inter-Asterisk eXchange (IAX) is a communications protocol native to the Asterisk private branch exchange (PBX) software, and is supported by a few other softswitches, PBX systems, and softphones. It is used for transporting VoIP telephony sessions between servers and to terminal devices. The original IAX protocol is deprecated and has been superseded by a second version, commonly called IAX2. The IAX2 protocol was published as an informational (non-standards-track) RFC 5456 by discretion of the RFC Editor in February 2010.

- **Zoiper configuration** : Soon available
- **IAXlite configuration** : Soon available
- **Yate client configuration** : Soon available

From:
<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:
<https://wiki.voximal.com/doku.php?id=voipproviders:iax>

Last update: **2017/02/03 22:26**

