

Call the test service

You can test your Voximal installation by calling the test numbers from any phone.

We setup 2 phone numbers :

- France : +33(0)9 72 53 88 23
- Unites States : +1-202-600-4534

You need to open the port 4569 from/to the internet. The calls will be transfered by this way to your Voximal server to the number/extension :

- **8965** ('VXML' from your phone dialpad).

By default, the Voximal installation configures the 'helloworld' service/account that executes this VoiceXML document :

- [helloworld.vxml](#)

When you call the voice portal, the service will request your PIN number.

Get your PIN from the Web Interface

With the Voxibot suite, the PIN number is prompted the main panel :

Test : Call +33(0)972 538 823 and enter your PIN XXXX

The screenshot displays the Voximal web interface. The top navigation bar includes 'Voximal', 'Reports', and 'Settings', along with a 'Logout: admin' button. The main content area is divided into several sections:

- System Overview:** Welcomes the user to IP-172-31-40-237. It provides a test instruction: 'Test : Call +33(0)972 538 823 and enter your PIN 2643'. A summary table shows the status of various components: Telephone (checked), Database (checked), Web Server (checked), and Interpreter (checked). A green box indicates 'System Alerts: No critical issues found'. A blue box shows 'There are 2 bad destinations' with a 'Show All' link.
- Uptime:** Shows 'System Last Rebooted' at '10 hours, 22 minutes, 37 seconds, ago'. Below this, 'Load Averages' are displayed for 1 Minute (0.01), 5 Minutes (0.03), and 15 Minutes (0.00).
- Telephony Statistics:** A chart showing 'Trunks Reged' (yellow), 'Trunks Offline' (red), and 'Active Calls' (blue). The y-axis ranges from 0 to 1.0.
- Interpreter Statistics:** Shows 'Sessions Status' with 'Pending' at 0 and 'Peak' at 1. Below this, 'Sessions Status' is detailed: 'Opened: 1', 'Error: 0', 'Refused: 0', and 'Max Duration: 4s'. 'Average Counters' are also shown: 'Duration: 4.00', 'Response: 1.00', and 'CAPS: 0.00'.

The footer contains the version '1.0.117' dated '7 Nov 21:11:28', the 'voximal' logo with the tagline 'The voice interaction', and a 'Support' button. A small window information box in the bottom right corner shows 'Window size: 1272 x 712' and 'Viewport size: 1280 x 720'.

With standard FreePBX distribution :

- Select Setting → Voximal Setting → Test

Voximal Settings

General | **TextToSpeech** | License | Call Test

An easy way to make tests.
To call your Voxibot :
Call the +33(0)972538823 and enter the PIN number.

PIN	?
Port number	4569

Version 1.0.121
18 Oct 10:10:11

voximal
The voice interaction

Support

Get your PIN from the Asterisk console

Execute :

```
raspbx*CLI> voximal show license
Version      : V14.0
Build
  CVS Revision : $Revision: 1.853 $
  Gcc          : V4.9
  Arch        : 32 bits
  Target      : i686
  Asterisk    : V13.11.2
  Options sum :
  Date       : Nov  3 2016 21:40:06
  Code      : b6de76bcb827eb415eb3b6f75b1001
  UID       : cb773b52-a362-11e6-af57-b827eb415eb3
  PIN       : 3152
  Password  : cb773b52
  Key       :
  Max sessions : 1
  Options
    TextToSpeech : Yes
    Speech       : Yes
  State      : ok
```

Your PIN is : **3152** (in this example)

From:
<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:
https://wiki.voximal.com/doku.php?id=installation_guide:test:start&rev=1478556612

Last update: **2016/11/07 22:10**

