# **Voximal Web Configuration**

### Access

All the configuration is managed throw a web interface based on the FreePBX project. To access to the web interface, open the link

#### http://your\_server\_address/admin.

It's protected by a login (the first login after the installation will request you a password).




## Login

After installation there are 3 default login accounts, with differents access permissions

- **user** : access to Voximal configuration and reports.
- admin : user access and network configuration
- root : full access (full freePBX features).

Each login have a default password (requested after the package installation, or the image activation), you can be change them with the root account.



# **System Status**

The home page after login show you the system status.

- Host name of the server
- Summary : Main modules status
- Interpreter statistics
- Telephony statistics
- Uptime / Load average

	Settings V Apply Config					Logout	t: admin Langua
System O	verview	0		Tele	phony Statistics		0
Welcome to	ivr.ulex.fr		Telephony -	Trunks Reged	Trunks Offline	<ul> <li>Active Calls</li> </ul>	
Summary	Sysinfo updated 1 seconds ago						8
Telephony 🗸			Uptime 👻				6.4
Database 🗸	System Alerts No critical issues found		CPU 🗸				4.8
Web Server  Interpreter	No childar issues found		Memory -				-
interpreter 🗸			Memory •				3.2
There are 10 bad destinations		•	Disk 🕶				1.8
Show	All		Network 🕶				0
Interpreter	Statistics	C			Uptime		2
Sessions	Status				•		N
Pending 0			System Last Rebooted				
Peak 1				1 day, 1 hou	r, 11 minutes, 33 seconds, a	go	
Opened: 6 Error: 0 Refused:	0 Max Duration: 81s				Load Averages		
Average Co	ounters		0.10		0.03	0.01	
Sessions		0.00	1 Min	ute	5 Minutes	15 Minutes	
Duration: 33.50 Response:							_

### Main configuration steps

2024/05/04 02:21

To configure the Voximal IVR you have 4 steps to do :

- 1. Configure the VoIP telephony access (SIP accounts)
- 2. Create/edit a VoiceXML service (Create a VoiceXML service)
- 3. Create Voximal accounts (Voximal accounts)
- 4. Configure the relation between the DID and the VoiceXML service you want to use (Routes configuration)

**Note**: On each configuration page, don't forget to click on **[Submit]** button at the bottom page before changing page. If you don't click on **[Submit]** you'll lose all your changes.

**Note**: All changes are not directly configure on the server. After one change, you'll see a button **[Apply Config]** in menu. To activate the changes on server <u>you have to click on</u> **[Apply Config]**.

#### 1) Configure the telephony access

#### a) Use the test number and the PIN

If your server is connected to the internet you can use the free test access to place calls to your server. There is nothing to do. You should only check that the port 4569 is open from/to internet in UDP.

#### b) Connect a trunk SIP

Before you can make external calls or accept incoming calls from outside, you need to setup SIP Trunks. You can choose any VoIP Service providers. You can create a SIP trunk with an operator referenced in the page Voip Providers. You have to enter informations :

- A trunk name : a string to identify you accounts
- The peers details : enter all trunk informations (host, username, password, type)

```
host=myprovider.com
username=0033123456789
type=peer
```

• Register informations : enter registry informations like :

0033123456789:password@myprovider.com/33123456789

• Click on [submit] button (don't remember to apply your modifications)



#### c) Add an extension

After you setup your Voxibot, the first thing you do is to add extensions (connect a Phone). The integrated FreePbx allows you to add a couple of different Device types

- Generic SIP Device
- Generic IAX2 Device
- Generic DAHDi Device
- Other Custom Device

Among these types, SIP device is the most common and popular one.

You can give your extension any unique number, Display Name, password, whether allow this extension to accept inbound external calls or can make outbound external calls. can have voicemail or not etc.

#### 2) Create a VoiceXML service

You need to create VoiceXML service, by uploading it or writing it directly with the embedded VoiceXML/PHP editor. Select the application menu **Voximal**.

#### Uploading VoiceXML service

	Accounts E				
irec	tory: / var / ww	/w / html / vxr	nl 🥔		
	Filename	Туре	Size (bytes)	Date Modified	
ŧ.	messaging.tgz	TGZ File	3,072,973	Aug 19 2015 3:53 PM	
ŧ.	dem o.tgz	TGZ File	137,915	Aug 17 2015 9:50 AM	
١.	vernai	<directory></directory>		Feb 8 2016 9:26 AM	
Û	messaging	<directory></directory>		Oct 29 2015 2:36 PM	
ŵ	app1	<directory></directory>		Jun 25 2015 5:56 PM	
Û	campaign	<directory></directory>		Apr 26 2016 4:58 PM	
1	tests	<directory></directory>		Mar 9 2016 10:45 PM	
Û	helloworld	<directory></directory>		Apr 27 2016 10:07 AM	
ŧ.	helloworld.vxm1	VXML File	536	Oct 14 2016 11:05 PM	
Û	demo	<directory></directory>		Oct 10 2016 5:17 PM	

In page Applications/Voximal click on **Editor** tab. At the end of the page, you have the way to upload files :

- Click on **Browse** and select your files (.vxml, .php, ...).
- Then click on [Upload]. Your files will appear in list.

#### Create VoiceXML service with editor

You can update VoiceXML file (extension .vxml), by clicking on the filename. The file content will appear, and you'll be able to update it, and check the syntax.

The editor page allow to create folders and files, and edit them.

To create folders or files, click on right items on top right corner (Create Directory or Create File).

Then enter filename, and click [Create].

Voximal Connectivity ⊽ Reports ⊽ Settings ⊽	Apply Config	Logout: admin	Language V
Voximal Application			
Editing file: / helloworld.vxml (?xml version="1.0"?> (vxml version="2.0" xmlns="http://www.w3.ou (cform) (var name="called" expr="session.conner (var name="id" expr="session.conner (var na	<pre>section.remote.uri"/&gt; section.local.uri"/&gt; m"/&gt; saller"/&gt;.</pre>		
Check			Þ
The Vxml syntax is valid			
Version 1.0.121 18 Oct 10:10:36		i	Support

### 3) Create a Voximal account

When your VoiceXML services is ready, you have to configure it in the server. To do it, add Voximal account. Select the **Voximal** menu item.

To create a Voximal Account, you have to define in minimum 2 required informations :

- 1. An application name, in field **Name**
- 2. The VoiceXML url of the service, in field **URL**. You can select a local one, in the list or writing a local or HTTP one.

There are several options :

- 1. **Max sessions** : you can define a specific limit, if you want lower maximum session than the license.
- 2. **Dial format** : you can define a specific dialout format for outgoing calls.
- 3. **Mark** : you can define a specific mark, that will appear in traces.
- 4. **Speech** : you can specify the use of the ASR. In case of using ASR server, the better way is to set **Automatic** choice.
- 5. **Max time** : you can set a maximum duration of call. If not setted or equals to 0, the duration is unlimited.
- 6. **Vxml parameter** : you can set a string to pass it to vxml script.
- 7. **Start delay** : you can set a time delay to start the service.

Accounts Ed	itor	
dd Applicatior		Add New Application
	th * can not be left in blank.	Cam paign Dem o HelloWord
ame* 🛛		messaging-consult messaging-depot
RL* 0	Select •	Saasivr SiteVernai
x Sessions		Tests Voximal_Access
al Format 🕫		
ırk 🖸		
eech 🕫	Emulation No Yes Automatic	
ix time (s) 🕫		
ssion parameter <sup>6</sup>		
art delay (ms) 🛛	2000	

#### 4) Number/Routes configuration

You have your DID number and SIP Trunk set up (with the test number, the called number will be 4568 : "VXML" in the dialpad). If you set up the inbound rules, you define when people call your DID number (for example 555-555-555) how your Voxiboy handle such call, normally you set up a Voximal Account (where you define the first VoiceXML document of your voice portal).

You can to define which application you want to use by default for all incoming calls. It's done by defining the **any DID/any CID** or **All DIDs** settings in **Connectivity/Numbers** page.

- 1. Select All DIDs item (on top right corner)
- 2. Leave empty Field **DID Number**
- 3. Select the application to use : Voximal Application
  - You can select an existing application (for example Voximal)
  - Or create a new one by clicking "Add new Voximal application"
- 4. Click on **[submit]** button.

Last update: 2016/10/25 installation\_guide:configuration:start https://wiki.voximal.com/doku.php?id=installation\_guide:configuration:start&rev=1477430907 21:28

Voximal Connectivity ⊽ Reg	orts V Settings V Apply Config	Logout: admin Langu
dd Incoming Route		Add Incoming Route
du meoning Route		All DIDs (toggle sort)
Add Incoming Route		User DIDs
		General DIDs Unused DIDs
Description 🕫		
		any DID / any CID
DID Number 🛛:		12345 test / any CID
CallerID Number 🕫		Demo
		01 / any CID
CID Priority Route <sup>10</sup> :		Echo Test 700 / any CID
Ontions		Goldorak
Options		0034911413999 / any CID
Alert Info 😶		HelloWorld 8965 / any CID
Alert Info 🖤:		Tests
CID name prefix <sup>2</sup> :		00 / any CID
		Voximal Demo 33972538733 / any CID
Signal RINGING <sup>20</sup> :		Voximal Test
Reject Reverse Charges 🕫		0033972538823 / any CID
Pause Before Answer 0:		
rause Before Answer		
Privacy		
Privacy Manager <sup>10</sup> :	No •	
Call Recording		
Call Recording <sup>2</sup> :	Allow	

# **Call Detail Record**


The CDR Reports allows you to view a report showing the telephone calls made from and received to your system. You can choose to view a complete history or calls, or to search by date, date range, number called, caller ID, etc.

			Apply Config							
eports										
Call Detail Record Search-										
Order By				Search	conditions					
Call Date      Call Date	From	n: 01 October	▼ 2016 ▼ 0	0: 00 то: 31	October	▼ 2016 ▼	23:59			Extra options
CallerID Number			Not: Begin	ns With:  Cont	tains: Ends	With: Exactly:	0			CDR search
CallerID Name			Not: Begin	ns With:   Cont	tains: O Ends	With: Exactly:	D		Report type :	□ : CSV file □ : Call Graph
Outbound CallerID Number	0		Not. Begin	ns With:   Cont	tains: O Ends	With: Exactly:	0		Result limit :	
			Not: Begin	ns With:   Cont	tains: O Ends	With: Exactly:	D		L	
Destination 2:			Not: Begin	ns With: 🖲 Cont	tains: O Ends	With: Exactly:	D			
Destination CallerID Name	0		Not: Begin	ns With: 🖲 Conf	tains: O Ends	With: Exactly:	D			
Userfield 0:		Not: 🔲 Begins With: 🖲 Contains: 🔘 Ends With: 🔍 Exactly: 🔘								
Account Code 😢			Not: 🔲 Begin	ns With:  Cont	tains: 🔍 Ends	With: Exactly:	D			
Duration 0:	Betw	veen: And:	Seconds							
Disposition 0:	All	Dispositions •	Not:							
Newest First <b>*</b>	Gro	up By: Day		•		Search				
			Call Detail	Record - Se	earch Retu	Irned 100 Ca	ls			
Call Date Recording	System	CallerID	Outbound CallerID	DID	App	Destination	Disposition	Duration	Userfield	Account 🦨
2016-10-18 00:21:13	1476742873.238	"Borja SIXTO " <11>	"Borja SIXTO " <11>		Dial	0170613300	ANSWERED	01:31		
2016-10-18 00:08:26	1476742106.222	"Borja SIXTO " <11>	"Borja SIXTO " <11>		Dial	0170613300	ANSWERED	00:38		
	1476741755.206		"Borja SIXTO " <11>		Dial	0170613300	ANSWERED	00:46		
	1476741373.190	"Borja SIXTO " <11>	"Borja SIXTO " <11>		Dial	0170613300	ANSWERED	00:46		
			"Borja SIXTO " <11>							

### Logs

The Asterisk Logfiles Module is an easy way to view portions of the Asterisk Log. However, this Module is only useful when you want to view a very recent event in the Asterisk Log.

You have similar Module for the Voximal log :



# Settings

a) General

Last update: 2016/10/25 installation\_guide:configuration:start https://wiki.voximal.com/doku.php?id=installation\_guide:configuration:start&rev=1477430907 21:28

Voximal Connectivity ⊽	Reports V Settings V Apply Config	Logout: admin	Language V
Voximal Settings			
General TextToSpeech	License Call Test		
UID 🤨	d2a9fd5e-6d96-11e5-b2cb-8d0ac9e2f828		
License 🔮	Remote Local		
Max sessions 🛛	5		
TTS	Enable		
ASR <sup>0</sup>	Enable		
License status <sup>2</sup>	ok		
Save Discard			
Jave			
	voximal		
Version 1.0.121	VOXIMOI		Cupped

#### b) TextToSpeech

18 Oct 10:10:03

Voximal Conne	ctivity V Reports V Settings V Apply Config	Logout admin	Language V
Voximal Setting	gS ToSpeech License Call Test		
Synthesis			
	HTTP or MRCP		
URI* 0	http://ttsc.voximal.net//tts/cereproc/tts.php		
Method <sup>1</sup>	POST GET ASTERISK		
Format <sup>©</sup>	wav wav16 pcm alaw ulaw raw sin sin16		
SSML	Yes No		
Cache ageing <sup>©</sup>	-1		
Cut prompt 9	Yes No		
Save Dis	card Cache clear		
Version 1.0.121 18 Oct 10:10:47			Support

The home page after login show you the system status.

- Host name of the server
- Summary : Main modules status
- Interpreter statistics

- Telephony statistics
- Uptime / Load average

#### d) License

#### c) Test number

	Voximal Connectivity ⊽	Reports ⊽ Settings ⊽	Apply Config		Logout: admin	Language V
Vox	General TextToSpeech	License Call Test		_		
	asy way to make tests. Il your Voxibot : he +33(0)972538823 and e	enter the PIN number.				
PIN	0	?				
Port	number 🕫	4569				
Version 1. 18 Oct 10					i	Support

## **Configuration files**

- /etc/voximald.conf (not modify this file)
- /etc/asterisk/voximal.conf (not modify directly this file)

From: https://wiki.voximal.com/ - Voximal documentation Permanent link: https://wiki.voximal.com/doku.php?id=installation\_guide:configuration:start&rev=1477430907 Last update: 2016/10/25 21:28

