

Option with Raspbx version



A 4GB card is required. First download the image disk to flash it in your MicroSD.

Get it from : [Downloads \(from raspberry-asterisk.org\)](#)

The latest image available for download is based on Raspbian (Debian 8 / Jessie) and includes:

- Asterisk 11.21.0
- FreePBX 13.0.74
- Torrent raspbx-06-03-2016.zip.torrent
- HTTP raspbx-06-03-2016.zip
- SHA-1 38665490e4ca3771ef39623c72019737d979e988

Follow those instruction : [Flash Image \(from raspberrypi.org\)](#)

RasPBX already install Asterisk with FreePBX so you only need to complete your installation with the Voximal package :

Get it from : [lastes Voximal for Raspbian package](#)

Connect to SSH (raspbx/raspberry) to complete the installation with the Voximal installer package. The default login acces is :

SSH login:

- user: root
- password: raspberry

Default FreePBX login:

- user: admin
- password: admin

```
Raspbian GNU/Linux8 raspbx tty1
```

```
raspbx login : root
```

```
Password:
```

```
Welcome to RasPBX - Asterisk for Raspberry Pi
```

```
RasPBX is based on Debian. The programs included with the Debian GNU/Linux system are free software; the exact distribution terms for each program are described in the individual files in /usr/share/doc/*/copyright.
```

```
RasPBX comes with ABSOLUTELY NO WARRANTY, to the extent permitted by
```

applicable law.

List of RasPBX specific commands:

```
-----  
-  
raspbx-upgrade      Keep your system up to date with the latest add-ons and  
                    security fixes  
configure-timezone  Set timezone for both system and PHP  
install-fax         Install HylaFAX  
add-fax-extension   Add additional fax extension for use with HylaFAX  
install-fail2ban    Install Fail2Ban for additional security  
install-dongle      Install GSM/3G calling capability with chan_dongle  
raspbx-backup       Backup your complete system to an image file
```

Last login: Sat Mar 5 18:56:10 2016

Once your RasPBX has successfully booted, run this command on the console to install the latest additions and improvements:

```
root@raspbx:~# raspbx-upgrade  
RasPBX upgrade tool  
Run "raspbx-upgrade --help" for additional options  
Base version: 06-03-2016  
Installed upgrade:      21  
Local upgrade available: 21  
Online upgrade available: 24  
Running apt-get update && apt-get dist-upgrade.  
  
... (lot of logs...)  
  
132 upgraded, 2 newly installed, 0 to remove and 0 not upgraded.  
Need to get 164 MB of archives.  
After this operation, 10.4 MB of additional disk space will be used.  
Do you want to continue? [Y/n] y  
  
... (installing packages...)  
  
Setting up libraspberrypi0 (1.20160620-1) ...  
Setting up libraspberrypi-dev (1.20160620-1) ...  
Setting up libraspberrypi-doc (1.20160620-1) ...  
Setting up libraspberrypi-bin (1.20160620-1) ...  
Setting up raspbx-upgrade (1.0-43) ...  
Setting up raspi-config (20160527) ...  
Installing new version of config file /etc/init.d/raspi-config ...  
Processing triggers for initramfs-tools (0.120+deb8u2) ...  
Processing triggers for libc-bin (2.19-18+deb8u4) ...  
Processing triggers for systemd (215-17+deb8u4) ...  
Installing upgrade 22.  
-----  
Fixing Asterisk startup problems in recent 2016 images  
-----
```

```

Installing upgrade 23.
-----
Increasing swap size to 200MB; installing en_US locale
-----
Generating locales (this might take a while)...
  en_GB.UTF-8... done
  en_US.UTF-8... done
Generation complete.
Installing upgrade 24.
-----
1. Updating GPG keys for FreePBX
2. Enabling Apache2 rewrite module
-----
gpg: refreshing 2 keys from hkp://pool.sks-keyservers.net
gpg: requesting key 69D2EAD9 from hkp server pool.sks-keyservers.net
gpg: requesting key B33B4659 from hkp server pool.sks-keyservers.net
gpg: key 69D2EAD9: "FreePBX Mirror 1 (Module Signing - 2014/2015)
<security@freepbx.org>" 2 new signatures
gpg: key B33B4659: "FreePBX Module Signing (This is the master key to sign
FreePBX Modules) <modules@freepbx.org>" 2 new signatures
gpg: Total number processed: 2
gpg:          new signatures: 4
gpg: 3 marginal(s) needed, 1 complete(s) needed, PGP trust model
gpg: depth: 0  valid:   1  signed:   1  trust: 0-, 0q, 0n, 0m, 0f, 1u
gpg: depth: 1  valid:   1  signed:   0  trust: 0-, 0q, 0n, 1m, 0f, 0u
Enabling module rewrite.
To activate the new configuration, you need to run:
  service apache2 restart
Finishing RasPBX upgrades installation, installed version is now: 24
root@raspbx:~#

```

```

[root]# ./voxibot_1.x.xx_2016xxxx_0voximalxxcentos6_all.run

[root]#

```

From:
<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:
https://wiki.voximal.com/doku.php?id=installation_guide:raspbx&rev=1473781630

Last update: **2016/09/13 15:47**

