DBL Technology Voip/GSM gateways

• Web site : http://www.dbltek.com/

DBL Technology Ltd. is a leading company in developing and manufacturing advanced voice over IP (VoIP) solutions for the worldwide market. We are dedicated in the development of the latest VoIP technologies, and more than 10 years in developing a wide range of IP Phones and Gateways. The offering of high quality, innovation, affordability and flexibility inside each and every single one of our products is our commitment to you.

• Installation :

- Insert a SIM card and connect the Gateway to your router.

- Call the SIM number and enter *01 to know the IP address.

- Open your web browser and set the IP to access to the configuration interface (the default user/password are admin/admin).

	15	V		no'	ne								简体中文
	GolP4												
Status	Line	М	SIM	GSM	VOIP	Status	SMS	RSSI	Carrier	BST ID	ldle	Remain	Reset
Summary	1	Y	Υ	Y	N	IDLE	N	14	Orange F		1234	NO LIMIT	Reset
General	2	N	N	N	N	IDLE	N	99			1234	NO LIMIT	Reset
GSM	3	N	Ν	N	N	IDLE	N				1234	NO LIMIT	Reset
SIM Call	4	N	N	N	N	IDLE	N				1234	NO LIMIT	Reset
Forward	ALL												Reset
Configurations													
Tools													

• Configuration :

SIP incomming trunk

```
[general]
Trunk Name: ovh-in (for example)
[Outgoing Settings]
```

```
Trunk Name: ovh-in (for example)

PEER Details:

type=peer

host=sipx.ovh.fr

username=00339xxxxxxx

fromuser=00339xxxxxxx

[Registration]
```

Register String: 00339xxxxxx:password@sipx.ovh.fr/00339xxxxxxx

SIP outgoing trunk

[general] Trunk Name: ovh-out (for example) [Outgoing Settings] Trunk Name: ovh-out (for example) PEER Details: type=peer host=sipx.ovh.fr username=00339xxxxxxx fromuser=00339xxxxxxx

From: https://wiki.voximal.com/ - **Voximal documentation**

Permanent link: https://wiki.voximal.com/doku.php?id=voipproviders:dbl&rev=1467736900



Last update: 2016/07/05 16:41