

# DBL Technology Voip/GSM gateways

- **Web site** : <http://www.dbltek.com/>

DBL Technology Ltd. is a leading company in developing and manufacturing advanced voice over IP (VoIP) solutions for the worldwide market. We are dedicated in the development of the latest VoIP technologies, and more than 10 years in developing a wide range of IP Phones and Gateways. The offering of high quality, innovation, affordability and flexibility inside each and every single one of our products is our commitment to you.

- **Installation** :

- Insert a SIM card and connect the Gateway to your router.
- Call the SIM number and enter \*01 to know the IP address.
- Open your web browser and set the IP to access to the configuration interface (the default user/password are admin/admin).



- Set Basic VOIP settings

The screenshot shows the 'SIP' configuration page of the EasyPhone GoIP4 interface. The left sidebar lists various configuration categories. The main area contains the following settings:

- Config Mode:** Single Server Mode
- Phone Number:** goip
- Display Name:** (empty)
- Authentication ID:** goip
- Password:** \*\*\*\*
- SIP Proxy:** (empty)
- SIP Registrar:** 192.168.1.17
- Re-register Period (s):** 10
- Outbound Proxy:** (empty)
- Home Domain:** (empty)
- Backup Server:**  Enable  Disable
- Routing Prefix:**  Line1  Line2  Line3  Line4
- Line 1 Routing Prefix:** (empty)
- Buttons:** \*Auto Config Other lines, Save Changes

- Set Call out settings



• **Configuration :**

**SIP incoming trunk**

```
[general]
Trunk Name: ovh-in (for example)

[Outgoing Settings]

Trunk Name: ovh-in (for example)
PEER Details:
  type=peer
  host=sipx.ovh.fr
  username=00339xxxxxxxx
  fromuser=00339xxxxxxxx
[Registration]

Register String: 00339xxxxxxxx:password@sipx.ovh.fr/00339xxxxxxxx
```

## SIP outgoing trunk

[general]

Trunk Name: ovh-out (for example)

[Outgoing Settings]

Trunk Name: ovh-out (for example)

PEER Details:

type=peer

host=sipx.ovh.fr

username=00339xxxxxxxx

fromuser=00339xxxxxxxx

From:

<https://wiki.voximal.com/> - **Voximal documentation**

Permanent link:

<https://wiki.voximal.com/doku.php?id=voipproviders:db1&rev=1467755985>

Last update: **2016/07/05 21:59**

